



Notes:

1. Refer to Henry Blueskin® Guide Specifications for substrate preparation requirements.
2. Surfaces to receive Blueskin® transition membrane must be properly prepared and primed according to Henry documents.
3. Pipe, conduit or duct must be secured to prevent movement.
4. If gap around penetration exceeds 1/2 inch, backer rod and/or compatible sealant must be used to support the membrane.

Henry
COMPANY®

AIR-BLOC 17MR AIR BARRIER

SCALE: N.T.S.

PIPE PENETRATION

10-07-14

**TYPICAL
DETAIL**