



Notes:

1. Refer to Henry Air-Bloc® Guide Specifications and Technical Data Sheets for recommended installation procedures and requirements.
2. Surfaces to receive Blueskin® transition membrane or Air-Bloc LF Liquid Flashing must be properly prepared and primed according to Henry documents.
3. Treat inside and outside corners with Blueskin® transition membrane or Air-Bloc LF Liquid Flashing extending a minimum of 3 inches on either side of the corner detail.



VAPOR PERMEABLE AIR-BLOC MEMBRANE

SCALE: N.T.S.

EXTERIOR SHEATHING

10-07-14

**CORNER
DETAILS**

LPS-08