



Notes:

1. Refer to Henry Air-Bloc Guide Specification for installation requirements.
2. Typical application sequence is to install the Blueskin membrane first, followed by the Air-Bloc liquid membrane.



VAPOR PERMEABLE AIR-BLOC MEMBRANE

SCALE: N.T.S.

BRICK VENEER/STEEL STUD WALL

10-07-14

**PARAPET
DETAIL**

LPS-01