



Notes:

1. Treat non-moving joints with an additional ply of polyester fabric set into wet CM100 membrane.
2. Extend polyester fabric minimum 76mm (3") over vertical and horizontal surfaces.
3. Protection coarse required over completed membrane application.

CM100 WATERPROOFING - HIGH BUILD SYSTEM

# CURB DETAIL

CONCRETE DECK

Scale: N.T.S.

Plot: 1:5

Issued: 08-14-97

Revision: 02

## CM-HB03



15 Wallsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com