


Notes:

1. Set 990-25_Elastomeric Flashing Sheet in a bed of wet CM100.
2. Coat 990-25_Elastomeric Flashing Sheet with CM100.
3. Set polyester reinforcing fabric into wet CM100.
4. Coat polyester reinforcing fabric with CM100.
5. Extend polyester fabric minimum 75mm (3") over vertical and horizontal surfaces.
6. Protection coarse required over completed membrane application.

<p>CM100 WATERPROOFING - HIGH BUILD SYSTEM</p> <p>CONSTRUCTION JOINT DETAIL</p> <p>CONCRETE DECK</p>	<p>Scale: N.T.S.</p>	<p>Plot: 1:5</p>	 <p>15 Walsend Drive, Toronto ON M1E 3X6 Technical Services - 800-486-1278 Email: techservices@henry.com www.ca.henry.com</p>
	<p>Issued: 08-14-97</p>	<p>Revision: 02</p>	
	<p>CM-HB04</p>		