



Metal Flashing
 modifiedPLUS® NP180gM4
 790-11 Membrane
 Adhesive
 Substrate

Stone Ballast or Pavers
 Filter Fabric
 Insulation
 Separation Layer
 790-11 Membrane
 Polyester Fabric Reinforcement
 790-11 Membrane
 modifiedPLUS® NP180s/s
 790-11 Membrane
 Adhesive
 Gypsum Sheathing
 Steel Deck

modifiedPLUS® NP180gM4
 790-11 Membrane
 Adhesive

150mm (6")

150mm (6")

Notes

1. The joints in the gypsum board sheathing are treated with pressure sensitive tape, min. 50mm (2") wide, prior to applying the 790-11.
2. An air/vapour barrier transition membrane such as Blueskin is installed prior to the wood parapet. This ties the 790-11 system into the wall air/vapour barrier to maintain continuity.

790-11 Membrane P.M.R. Assembly

TYPICAL PARAPET

STEEL DECK

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

HR-10E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com