



### Notes

1. The joints in the gypsum board sheathing are treated with pressure sensitive tape, min. 50mm (2") wide, prior to applying the 790-11.
2. An air/vapour barrier transition membrane such as Blueskin is installed prior to the wood parapet. This ties the 790-11 system into the wall air/vapour barrier to maintain continuity.

790-11 Membrane P.M.R. Assembly

## TYPICAL PARAPET

STEEL DECK

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

# HR-10E97



15 Wallsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com