



**Notes**

1. System detail showing modifiedPLUS G100p/p base sheet and a modifiedPLUS NP180gT4 cap sheet, a two ply thermofused SBS modified bitumen flashing membrane system.
2. The two SBS modified bitumen membranes are typically thermofused in place prior to applying the 790-11 membrane system.
3. The adhesives for the 790-11 and the modifiedPLUS membranes are the same. Use either Poly-Tac™ a polymer modified adhesive or 910-01 an asphalt penetrating adhesive.
4. Alternatively, for wood parapets use modifiedPLUS® NP180 Tack Sheet a self-adhered base sheet in place of the modifiedPLUS® G100p/p. Use either 930-38 or 900-34, primer for the modifiedPLUS® NP180 Tack Sheet.
5. The joint between the plywood sheathing and the gypsum board sheathing is reinforced with a 150mm (6") strip of modifiedPLUS® NP180s/s.

790-11 Membrane P.M.R. Assembly

**TYPICAL PARAPET**

STEEL DECK

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

**HR-12E97**



15 Wallsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com