

Notes

- 1. The flashing sheet can be either modifiedPLUS® NP180s/s or 990-25 Flashing Sheet.
- 2. The flashing sheet is set in a 3mm (125 mils) bed of 790-11 prior to installing the membrane in the field.
- 3. The first coat of 790-11 should be applied to a thickness of 2mm (80 mils) min. prior to the application of the Polyester Fabric. The second coat is applied to a thickness of 3mm (125 mils) min.

790-11 Membrane P.M.R. Assembly

CONSTRUCTION JOINT

CONCRETE DECK

Scale: N.T.S. Plot: 1:5

Issued: 05-14-97 Revision: 05

HR-13E97



I 5 Wallsend Drive, Toronto ON MIE 3X6 Technical Services - 800-486-1278 Email: techservices@henry.com www.ca.henry.com