



### Notes

1. The 790-11 membrane may be applied prior to the construction of the parapet wall. Ensure proper trade coordination.
2. This detail applies to precast or hollow core slab construction.
3. Adhesive shall be Poly-Tac™ 930-18 polymer modified adhesive or 910-01 an asphalt penetrating adhesive.

790-11 Membrane P.M.R. Assembly

## PRECAST WALL EDGE DETAIL

PRECAST CONCRETE DECK

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

# HR-18E97



15 Wallsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com