



**Notes**

1. The flashing sheet can be either modifiedPLUS® NP180s/s or 990-25 Flashing Sheet.
2. Follow appropriate codes for minimum vent height above roof deck.
3. Keep the flashing sheet 12mm (1/2") back from the vent stack and carry the 790-11 membrane up to the stack to ensure a complete seal.

790-11 Membrane P.M.R. Assembly

**VENT/PROJECTION**

CONCRETE DECK

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

**HR-19E97**



15 Wallsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com