



Notes:

1. Substrates to which 790-11 and WP200 will be installed must be properly prepared and primed per Henry requirements.
2. Refer the Henry 790-11 and WP200 Technical Data Sheets and Guide Specification for installation requirements.

BLUESKIN WP200 ONTO 790-11

DECK/WALL DETAIL

WATERPROOFING SYSTEM TIE-IN

Scale: N.T.S.

Plot: 1:5

Issued: 06-01-15

Revision: 01

HR-22E15



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com