



Notes

1. Cant strips are not required when the cap sheet flashing or all plies are thermofused.
2. Bevelled edges on poured concrete corners are recommended.
3. A drainage layer or channeled insulation panels may be used.
4. The base sheet may extend 25mm (1") up the vertical to provide temporary watertightness. Ensure edge is sealed.

modifiedPLUS® Roofing Systems

PARAPET DETAIL

P.M.R. ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-15E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com