



Notes

1. There are two types of adhesives for torch applied modifiedPLUS® membranes: 910-01 an asphalt penetrating adhesive and Poly-Tac® 930-18 a polymer modified adhesive. Superior membrane to deck adhesion is provided when Poly-Tac® 930-18 adhesive is used.
2. Drain designs vary. Always refer to drain manufacturer's recommendations.
3. The base sheet flashing and the cap sheet should be mechanically clamped.

modifiedPLUS® Roofing Systems

ROOF DRAIN

P.M.R. ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-16E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com