



Notes

1. Duratac[®] SA is a self-adhered roofing membrane system.
2. The Re-Cover Board overlay is mandatory on all insulated applications.
3. Wood cant strips are required when installing Duratac[®] SA roofing membrane systems. Priming is required for all substrates, except to Re-Cover Board.
4. An air/vapour barrier transition membrane such as Blueskin[®] is installed prior to building the wood parapet. This ties the roofing system into the air/vapour barrier to maintain continuity.

Duratac[®] SA Roofing Systems

PARAPET DETAIL

SELF-ADHERED ROOFING ASSEMBLY

Scale: N.T.S.	Plot: 1:5
Issued: 09-01-00	Revision: 03

MB-19E00



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com