



Notes

1. Cant strips are not required when the cap sheet flashing or all plies are thermofused.
2. Mechanical fasteners should be spaced at 200mm (8") o.c. on the outside and 450mm (18") on the inside of the parapet.
3. The air/vapour barrier membrane may be a modifiedPLUS membrane.
4. The base sheet may extend 25mm (1") up the vertical to provide temporary watertightness. Ensure edge is sealed.

modifiedPLUS® Roofing Systems

PARAPET DETAIL

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-2E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com