



Notes

1. The reglet should be a minimum of 200mm (8") from the finished roof surface.
2. Ensure reglet is blown clean prior to applying sealant.
3. The modifiedPLUS® membranes may be thermofused, self-adhered, applied in hot asphalt, or applied in cold adhesive. Consult Technical Data Sheets for specific information as well as surface preparation requirements.

modifiedPLUS® Roofing Systems

REGLET COUNTERFLASHING

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-3E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com