



Notes

1. Fasten the metal flashing to the wood blocking in a staggered pattern. Frequent fastening will reduce thermal movement.
2. Ensure deck slopes to drain, scupper or eavestrough on perimeter.

modifiedPLUS® Roofing Systems

ROOF EDGE

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-5E97



15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com