



Notes

1. Fasten cant strip using mechanical fasteners.
2. Extend the base flashing sheet down the outside face beyond wood blocking and fasten at 200mm (8") o.c.

modifiedPLUS® Roofing Systems

**CANTED
ROOF EDGE**

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-6E97



15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com