



Notes

1. The membranes should be mechanically clamped by the drain assembly.
2. A minimum slope of 1:50 (1/4":12) to drain is recommended.
3. Drainage in the immediate area around the drain may be facilitated by tapering the insulation and incorporating a sump.
4. Position base sheet flashing 45 degrees to the base sheet. Use a full width sheet cut square, 1m x 1m (39" x 39").
5. Drain designs vary. Always refer to drain manufacturer's recommendations.

modifiedPLUS® Roofing Systems

ROOF DRAIN

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

MB-8E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com