



NOTES:

1. DETAIL SHOWS **HENRY® 790-11/790-11EV** REINFORCED HOT RUBBERIZED ASPHALT WATERPROOFING ASSEMBLY FIELD MEMBRANE TRANSITION WITH **HENRY® PUMADEC™ FLEX 31MV** OR **PUMADEC™ FLEX 30SL**.
2. RECOMMENDED **HENRY®** ADHESIVE/PRIMER FOR **790-11/790-11EV** INCLUDE: **910-01 ASPHALT PRIMER** OR **930-18 POLYMER MODIFIED ADHESIVE**. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET TO CONFIRM VOC COMPLIANCE.
3. FOR LONG-TERM COLOUR STABILITY: REFER TO DETAIL PUMADEC-SD2 FOR **PUMADEC™** SYSTEM WITH **HENRY® DEQCOAT™** TOP COAT.
4. PREPARE AND PRIME SUBSTRATES A MINIMUM 50 mm BEYOND **PUMADEC™** SYSTEM APPLICATION IN ACCORDANCE WITH **HENRY® PUMADEC™** SYSTEM SUBSTRATE PREPARATION GUIDELINES.
5. BROADCAST SIEVE SIZE NO. 30 (OR OTHER AS APPROVED BY **HENRY®**) SILICA SAND INTO WET **PUMADEC™** RESIN AT ANTICIPATED OVERLAP AREA UNTIL REJECTION AND ALLOW MEMBRANE TO FULLY CURE; REMOVE EXCESS SAND PRIOR TO **790-11/790-11EV** ASSEMBLY INSTALLATION.
6. **HENRY®** OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS. CONTACT **HENRY®** FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
7. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
8. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry®

15 Wallsend Drive
 Scarborough, Ontario, Canada, M1E 3X6
 800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. **HENRY®** DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEC™ FLEX 31MV OR FLEX 30SL TRANSITION - HENRY® 790-11

SYSTEM TRANSITION

790-11/790-11EV WITH PUMADEC™ SYSTEM
 PMR, IRMA, PLAZA DECKS AND TERRACES - OPTION 1

SCALE: N.T.S.

04-17-2018

PUMADEC-A1