



NOTES:

1. DETAIL SHOWS HENRY® **790-11, 790-11EV** OR **CM100** FIELD MEMBRANE WITH HENRY® **PUMADEC™ FLEX 31MV** OR **PUMADEC™ FLEX 30SL** FLASHING.
2. REFER TO PRODUCT SPECIFIC TDS FOR FIELD MEMBRANE ASSEMBLY COMPONENTS.
3. PRIMER FOR **790-11/790-11EV** NOT SHOWN FOR CLARITY. RECOMMENDED HENRY® ADHESIVE/PRIMER FOR **790-11/790-11EV** INCLUDE: **910-01 ASPHALT PRIMER** OR **930-18 POLYMER MODIFIED ADHESIVE**. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET TO CONFIRM VOC COMPLIANCE.
4. FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 65 °C.
5. FOR LONG-TERM COLOUR STABILITY: REFER TO DETAIL PUMADEC-SD2 FOR **PUMADEC™** SYSTEM WITH HENRY® **DEQCOAT™** TOP COAT.
6. PREPARE AND PRIME SUBSTRATES A MINIMUM 50 mm BEYOND **PUMADEC™** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY® **PUMADEC™** SYSTEM SUBSTRATE PREPARATION GUIDELINES.
7. LIGHTLY SAND PIPE AND WIPE WITH **PUMADEC™** CLEANING FLUID AND CLEAN CLOTH PRIOR TO **PUMADEC™** PRIMER INSTALLATION.
8. REFER TO REFER TO **PUMADEC™** SYSTEM TRANSITION DETAILS FOR PRODUCT SPECIFIC TRANSITION REQUIREMENTS.
9. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
10. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry®

15 Wallsend Drive
Scarborough, Ontario, Canada, M1E 3X6
800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEC™ FLEX 31MV OR PUMADEC™ FLEX 30SL FLASHING

PIPE PENETRATION

790-11/790-11EV/CM100 WITH PUMADEC™ SYSTEM
FLASHING ON A HORIZONTAL SUBSTRATE - OPTION 2

SCALE: N.T.S.

04-17-2018

PUMADEC-P1K