



Notes

1. Joint surfaces should be clean and dry before priming and prior to placing the Synko-Flex®, Synko-Flex® FR or Hydro-Flex® strips.
2. Prime using SF311 - SYNKO-FLEX® Solvent Based Primer or SF300 – Synko-Flex® Emulsion Primer. Refer to product technical data sheet for more information.
3. Concrete should cure a minimum of 24 hours prior to priming.
4. Concrete keyway is not required for the use of this product.
5. Minimum of two inches of concrete coverage is recommended.
6. Splice the end of each strip to the next strip with a 25mm (1") overlap.

Synko-Flex® & Hydro-Flex® Waterstop

FOUNDATION WALL & FOOTING DETAIL

PREFORMED ADHESIVE WATERSTOP

Scale: N.T.S.

Author: CA

Issued: 01-11-16

Revision: 01

SF-4B16

Henry®

15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com