



**Notes:**

1. Detail shows 2 ply reinforced 790-11EV membrane installed over concrete deck.
2. Comply with appropriate codes for minimum vent height.
3. Refer to Henry 790-11EV Guide Specification for specific installation procedures.
4. Pipe must be fully grouted or cast in place to prevent movement.

790-11EV WATERPROOFING MEMBRANE

**PLUMBING VENT DETAIL**

TYPICAL VRA ROOF ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-22-13

Revision: 00

**VR-10E13**



15 Wallsend Drive, Toronto ON M1E 3XG  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com