



Notes:

1. Detail shows 2 ply reinforced 790-11EV membrane installed over concrete deck.
2. Refer to Henry 790-11EV Guide Specifications and Technical Data Sheets for installation procedures.
3. Vegetation to be no closer than 300mm (12") to drain.

790-11EV WATERPROOFING MEMBRANE

ROOF DRAIN DETAIL

TYPICAL VRA ROOF ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-22-13

Revision: 00

VR-8E13



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com