



- Vegetation
- Growing Media
- Filter Fabric
- Moisture Retention Mat (optional)
- DB50 or DB100 Water Retention Insulation
- Insulation
- Root Bloc 20
- G100ss Protection Course
- 790-11EV Membrane
- Polyester Reinforcement
- 790-11EV Membrane
- Adhesive/Primer (not shown)
- Concrete Deck

Notes:

1. Detail shows 2 ply reinforced 790-11EV membrane installed over concrete deck.
2. Refer to Henry 790-11EV Guide Specification for specific installation procedures.
3. Pipe must be fully grouted or cast in place to prevent movement.

<p>790-11EV WATERPROOFING MEMBRANE</p> <p>CONTINUOUS PIPE PENETRATION DETAIL</p> <p>TYPICAL VRA ROOF ASSEMBLY</p>	<p>Scale: N.T.S.</p> <hr/> <p>Issued: 05-22-13</p>	<p>Plot: 1:5</p> <hr/> <p>Revision: 00</p>	<p>Henry</p> <hr style="width: 50%; margin: auto;"/> <p>BAKOR</p> <p style="font-size: small;">15 Wallsend Drive, Toronto ON M1E 3X6 Technical Services - 800-486-1278 Email: techservices@henry.com www.ca.henry.com</p>
VR-9E13			