



Notes

1. Where the interior floor slab is raised a minimum of 150mm (6") from the top of the footing to the underside of the the interior slab the additional reinforcing strip may be omitted.
2. See Technical Data Sheets for requirments of membrane protection.
3. Place drainage composite with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

RAISED SLAB DETAIL

SELF-ADHERED WATERPROOFING
SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WP-4B98

Henry
BAKOR

15 Wallsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com