



Notes

1. Where the interior floor slab is raised a minimum of 150mm (6") from the top of the footing to the underside of the the interior slab the additional reinforcing strip may be omitted.
2. See Technical Data Sheets for requirments of membrane protection.
3. Place Henry-Bakor DB 6000 with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200
**RAISED SLAB
 DETAIL**

SELF-ADHERED WATERPROOFING
 SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WP-4B98



15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com