



Notes

1. The Blueskin® WP 200 membrane is extended 300mm (12") below the deck-to-wall joint.
2. Two plies of Blueskin® WP 200 are used at all 90 degree changes in plane.
3. See Technical Data Sheets for requirements of membrane protection.
4. Place Henry-Bakor DB 6000 with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

DECK TO WALL DETAIL

SELF-ADHERED WATERPROOFING
SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WP-5B98

Henry
BAKOR

15 Wallsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com