



Notes

1. The Blueskin® WP 200 membrane is extended 300mm (12") below the deck-to-wall joint.
2. Two plies of Blueskin® WP 200 are used at all 90 degree changes in plane.
3. See Technical Data Sheets for requirements of membrane protection.
4. Place drainage composite with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

DECK TO WALL DETAIL

SELF-ADHERED WATERPROOFING
SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WP-5B98

Henry
BAKOR

15 Walsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com