



Notes

1. Counter flashing, reglet and termination bar details are acceptable.
2. A termination bar must be used on all deck-to-wall expansion joint details.
3. See Technical Data Sheets for requirements of membrane protection.
4. Place drainage composite with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

TERMINATION BAR DETAIL

SELF-ADHERED WATERPROOFING
SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 05

WP-7B98

Henry
BAKOR

15 Wallsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com