


**Notes**

1. Termination detail may also be a reglet/ counter flashing.
2. Seal all terminations with HE925 BES Sealant or Polybitume® 570-05 not covered on same day by field membrane.
3. A termination bar must be used on all deck-to wall expansion joint details.
4. See Technical Data Sheets for requirements of membrane protection.
5. Place Henry-Bakor DB 6000 with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

|   |  |                                      |   |
|---|--|--------------------------------------|---|
| <p>Blueskin® WP 200</p> <p><b>EXPANSION JOINTS</b></p> <p>SELF-ADHERED WATERPROOFING SYSTEM</p> | <p>Scale: N.T.S.</p> <p>Issued: 02-14-98</p> | <p>Plot: 1:5</p> <p>Revision: 05</p> |  <p>15 Walsend Drive, Toronto ON M1E 3X6<br/>         Technical Services - 800-486-1278<br/>         Email: techservices@henry.com<br/>         www.ca.henry.com</p> |
| <p>WP-8B98</p>  |  |                                      |   |