



Notes

1. Termination detail may also be a reglet/ counter flashing.
2. Seal all terminations with HE925 BES Sealant or Polybitume® 570-05 not covered on same day by field membrane.
3. A termination bar must be used on all deck-to wall expansion joint details.
4. See Technical Data Sheets for requirements of membrane protection.
5. Place drainage composite with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

EXPANSION JOINTS

SELF-ADHERED WATERPROOFING SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 05

WP-8B98



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com