



Notes

1. The flashing sheet can be either modifiedPLUS® NP180s/s or 990-25 Flashing Sheet.
2. The flashing sheet is set in a 3mm (125 mils) bed of 790-11 prior to installing the membrane in the field.
3. The first coat of 790-11 should be applied to a thickness of 2mm (80 mils) min. prior to the application of the Polyester Fabric. The second coat is applied to a thickness of 3mm (125 mils) min.

790-11 Waterproofing

**EXPANSION
JOINT**

JOINTS UP TO 12mm IN WIDTH

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WPR-12B98



15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com