



Notes

1. Follow appropriate codes for minimum vent height above roof deck.
2. Keep the flashing sheet 12mm (1/2") back from the vent stack and carry the 790-11 membrane up to the stack to ensure a complete seal.

790-11 Waterproofing

VENT DETAIL

NOT CAST-IN-PLACE

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WPR-13B98



15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com