



Notes

1. The flashing sheet is set in a 3mm (125 mils) bed of 790-11 prior to installing the membrane in the field.
2. The first coat of 790-11 should be applied to a thickness of 2mm (80 mils) min. prior to the application of the Polyester Fabric. The second coat is applied to a thickness of 3mm (125 mils) min. for a total thickness of 5mm (215 mils).

790-11 Waterproofing
**CONSTRUCTION
 JOINT**
 CONCRETE DECK

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WPR-7B98



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com