

Brick-Tie with
Insulation Retainer

Brick Veneer
Air Space
Insulation
Blueskin® SA or TG
Blueskin® Adhesive
Concrete Masonry Unit
Furring
Gypsum Board

HE 925 BES Sealant
(or) Polybitume® 570-05

Blueskin® TWF
Thru-Wall Flashing
Sheet

Air-Bloc 21 or 230-21
Rigid Insulation Adhesive

Blueskin® SA or TG

Notes:

1. When Blueskin® membranes are used for the air/vapour barrier; the brick tie system can be installed after the Blueskin® is installed. This helps assure continuity and significantly reduces installation time.
2. It is recommended that the insulation be in tight contact with the air/vapour barrier.
3. When the brick-tie system is installed prior to the Blueskin®, the membrane is cut, fitted and sealed with Air-Bloc 21 around each tie projection. A 50mm(2") lap is needed over the ties.
4. Seal upper edge of Blueskin® TWF with HE925 BES Sealant or Polybitume® 570-05.

Blueskin® SA or Blueskin® TG

SHELF ANGLE DETAIL

BRICK VENEER / CONC. BLK. WALL

Scale: N.T.S.

Plot: 1:5

Issued: 08-14-97

Revision: 07

AB-8B96



15 Walsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com