



**NOTES:**

1. DETAIL SHOWS **AIR-BLOC® 16MR** ASSEMBLY INSTALLED OVER EXTERIOR GRADE GYPSUM SHEATHING. OTHER ACCEPTABLE SUBSTRATES INCLUDE PLYWOOD, OSB, CONCRETE, AND CONCRETE BLOCK.
2. INSULATION AND CLADDING NOT SHOWN FOR CLARITY.
3. PRETREAT INSIDE CORNERS WITH A 12 mm BEAD OF **POLYBITUME® 570-05, 925 BES SEALANT, OR AIR-BLOC® LF**. TOOL SEALANT IMMEDIATELY AFTER APPLICATION TO FORM A SMOOTH FILLET BEAD.
4. WRAP FLASHING A MINIMUM OF 76 mm PAST CHANGE OF PLANE AT INSIDE AND OUTSIDE CORNERS.
5. PRIME RAW EDGES OF EXTERIOR GYPSUM SHEATHING WHERE **AIR-BLOC® LF** IS ANTICIPATED TO LAP ONTO CUT AND EXPOSED GYPSUM CORE. RECOMMENDED PRIMER/ADHESIVE INCLUDE: **BLUESKIN® SPRAY PREP**.
6. ALLOW **AIR-BLOC® 16MR** TO FULLY CURE PRIOR TO INSTALLATION OF SUBSEQUENT MATERIALS.
7. REFER TO **AIR-BLOC® 16MR** GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

**Henry®**

15 Wallsend Drive,  
Scarborough, Ontario, M1E 3X6  
800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

**AIR-BLOC® 16MR AIR AND VAPOUR BARRIER**

**INSIDE AND OUTSIDE CORNERS**

SCALE: N.T.S.

10-25-2016

**AB16MR - 3A**