



**NOTES:**

1. DETAIL SHOWS **BLUESKIN® VP160** ASSEMBLY INSTALLED OVER EXTERIOR GRADE GYPSUM SHEATHING. OTHER ACCEPTABLE SUBSTRATES INCLUDE PLYWOOD, OSB, CONCRETE, AND CONCRETE BLOCK.
2. PRETREAT INSIDE CORNERS WITH A 12 mm BEAD OF **925 BES SEALANT**. TOOL SEALANT IMMEDIATELY AFTER APPLICATION TO FORM A SMOOTH FILLET BEAD.
3. WRAP **BLUESKIN® VP160** A MINIMUM OF 76 mm PAST CHANGE OF PLANE AT INSIDE AND OUTSIDE CORNERS.
4. ENSURE MINIMUM OF 50 mm OVERLAP AT HORIZONTAL LAPS AND 76 mm OVERLAP AT VERTICAL LAPS.
5. REFER TO **BLUESKIN® VP160** INSTALLATION GUIDELINES FOR RECOMMENDED INSTALLATION PROCEDURES.

**Henry®**

15 Wallsend Drive,  
 Scarborough, Ontario, M1E 3X6  
 800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

**BLUESKIN® VP160 SELF-ADHERED WATER RESISTIVE AIR BARRIER**

**INSIDE AND OUTSIDE CORNERS**

SCALE: N.T.S.

09-29-2016

**BSVP160 - 3A**