



Notes

1. The modifiedPLUS® NP180gT4 flashing membrane is thermofused to the primed substrate (non-combustible) and can be left exposed.
2. An air/vapour barrier transition membrane such as Blueskin® is installed prior to building the wood parapet. This ties the 790-11 system into the wall air/vapour barrier to maintain continuity.
2. The modifiedPLUS® membrane must be mechanically fastened at 200mm (8") o.c. along the outside face.
3. Set granules in the modifiedPLUS® NP180gT4 membrane using a heated trowel to improve adhesion of the 790-11 membrane.

790-11 Membrane P.M.R. Assembly

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

TYPICAL PARAPET

STEEL DECK

HR-11E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com