



Notes

1. The gap between the vent stack and vent flashing shall be insulated to prevent condensation. Seal the top with mastic and fasten cap.
2. A vapour retarder may be used to wrap the insulation layer at the vent.
3. The vent flashing is set in HE925 BES Sealant (or) Polybitume® 570-05 and the top surface is primed prior to installing the membrane.
4. Duratac® SA is a self-adhered roofing membrane system. Consult Technical Data Sheets for specific information as well as priming requirements.

Duratac® SA Roofing Systems

VENT FLASHING

SELF-ADHERED ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 09-01-00

Revision: 03

MB-20E00



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com