



Notes

1. A 19mm x 19mm (3/4"x3/4") fillet of HE925 BES Sealant (or) Polybitume® 570-05 is formed where the foundation wall and footing meet to provide additional protection.
2. A 228mm (9") reinforcing strip of Blueskin® WP 200 is applied at 90 degree changes in plane.
3. Terminations in the membrane are sealed using either HE925 BES Sealant or Polybitume® 570-05 Polymer Modified Sealing Compound.
4. See Technical Data Sheets for requirements of membrane protection.
5. Place Henry-Bakor DB 6000 with fabric side outwards. Attach to vertical surfaces using Bakor 230-21 Rigid Insulation Adhesive, two-sided tape, mechanical fastening with nails and washers, or other approved method. Permanent fixing is achieved once the backfilling operation is complete.

Blueskin® WP 200

WALL/ FOOTING DETAIL

SELF-ADHERED WATERPROOFING
SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 04

WP-3B98

Henry
BAKOR

15 Walsend Drive, Toronto ON M1E 3X6
Technical Services - 800-486-1278
Email: techservices@henry.com
www.ca.henry.com